



REAR VIEW AND CONNECTORS



<CN702 12P CONNECTOR>




1. Audio Right (+)
2. Audio Left (+)
3. Signal Ground
4. Mute
5. Power Supply, +B
6. Audio Right (-)


7. Audio Left (-)
8. Ground
9. Communicat
10. Communicat
- 11.
12. Power Supp

Aftermarket Stereo

25-1111

SWITCHED IGNITION POWER	
CONSTANT BATTERY POWER	
CHASSIS NEGATIVE GROUND	
ILLUMINATION	
AMPLIFIER TURN ON	
POWER ANTENNA	
DIMMER	
LEFT FRONT POSITIVE	
LEFT FRONT NEGATIVE	
LEFT REAR POSITIVE	
LEFT REAR NEGATIVE	
RIGHT REAR POSITIVE	
RIGHT REAR NEGATIVE	








Power Antenna

Remote Turn On

Battery

Accessory

Illumination



Components
Car Radio Battery Constant 12V+ Wire
Car Radio Accessory Switched 12V+ Wire
Car Radio Ground Wire
Car Radio Illumination Wire
Car Radio Antenna Trigger Wire
Left Front Speaker Positive Wire (+)
Left Front Speaker Negative Wire (-)
Right Front Speaker Positive Wire (+)
Right Front Speaker Negative Wire (-)
Left Rear Speaker Positive Wire (+)
Left Rear Speaker Negative Wire (-)
Right Rear Speaker Positive Wire (+)
Right Rear Speaker Negative Wire (-)